


# **Installation Guide**

## **Towel Warmers**

### **S08**



**Plug-In  
VERSION**

# **IMPORTANT SAFETY INSTRUCTIONS**

When using this electrical equipment, basic safety precautions should always be followed, including the following:

READ ALL FOLLOW INSTRUCTIONS

CAUTION: Do not use near water, bathtub, sink or any other container.

CAUTION: Hot Surface. Avoid Contact.

CAUTION: To provide continued protection against risk of electric shock, connect to properly grounded outlets only.

WARNING - To reduce the risk of injury, do not permit children to use this product.

Children should be supervised to ensure that they do not play with the appliance.

The max load allowed to be putted on this appliance is 10kg.

## **SAVE THESE INSTRUCTIONS**

# Contents

---

|                                         |    |
|-----------------------------------------|----|
| Safety Hazard Prevention Measures ..... | 01 |
| Controller Operating Instructions ..... | 02 |
| Product Related Information .....       | 03 |
| Bill Of Material .....                  | 03 |
| Exploded View .....                     | 04 |
| Installation Procedure .....            | 05 |

### Instructions for safety

Please read all the contents of this manual carefully before using this product.

- Keep this manual safe.
- Any installation or operation not in accordance with the instructions may result in serious injury, property damage or damage to the product itself.




### NOTE

- This appliance must be installed by a qualified and licensed electrician and in accordance with all applicable electrical codes.
  - Avoid using abrasive cleaning agents or those containing ammonia to clean the surface of the product, it is recommended to clean it with warm water and dry with a microfiber cloth..
  - To avoid potential injury to infants or young children, appliances should be installed so that the lowest heated towel rack (or control section) is at least 24 inches from the floor.
  - The product connection must be grounded reliably.
  - Do not install switches or fuses on ground wires and neutral wires, and do not connect ground wires to water mains, gas pipes or heating pipes.
  - This appliance must be installed by a qualified and licensed electrician and in accordance with all applicable electrical codes.
  - Prolonged contact with skin may cause burns even at a low temperature.
  - Do not remove the labels on the upper and lower legs before installation.
  - The appliance is intended for indoor use as a room heater and for the heating and drying towels or similar textiles. It is not intended to come in contact with corrosive materials. When the appliance is in operation, please use care when placing delicates, silk, or acrylic textiles as the appliance reaches high temperatures when covered.
  - Do not use water to extinguish a fire before the power is off.
  - The appliance must not be placed directly under an electrical outlet. Keep the appliance a reasonable distance from water sources (a minimum of 24 inches as required by code).
- Do not use an electric towel rack if you notice any of the following, or if you are concerned about other safety issues. An explosion, a hissing sound, or a strong smell or smoke coming from inside the towel rack. These conditions generally occur when an internal electronic component fails in safe and controllable mode. However, the occurrence of these situations in general may also indicate that there is a security risk. Do not assume a safety failure, turn off the towel rack, and disconnect the power supply at the service panel. Immediately contact the seller and a qualified and certified electrician to inspect the appliance before using again. and then contact the relevant technical support department for help.

### Maintenance & Repair

- All repairs must be performed by a qualified and licensed electrician.
- Turn off the power after each use.
- It is not recommended to keep the appliance idle and in the off position for extended periods of time between use as it may result in the accumulation of moisture inside the appliance negatively impacting the insulation.
- If the power supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified personnel in order to avoid a hazard.
- The on/off control should be placed in the off position before the electrical appliance connected to power on for trial operation. Power on, commissioning, shutdown and other processes should be strictly in accordance with the instructions contained herein, Power off after the occurrence of any abnormal phenomena, and immediately contact the seller.

## CONTROLLER OPERATING INSTRUCTIONS



**Power:** Short press to enter standby or turn off.

**Constant Temperature Mode:**

Constant Temperature Mode is the factory default setting.

**Drying switch:** Short press to turn towel bar surface heating on/off. In this mode, the towel bar operates at the preset temperature of 122°F.

**Fan Heater Switch:** No response.

**Heating Mode:**

Long press the heater switch for 3 seconds to enter Heating Mode.

**Drying switch:** Short press to turn towel bar surface heating on/off. In this mode, the towel bar operates at the preset temperature of 158°F.

**Fan Heater Switch:** Short press to turn the warm-air system on/off.


PRODUCT RELATED INFORMATION

|                 |       |
|-----------------|-------|
| Product number  | S08   |
| Rated voltage   | 120V  |
| Rated frequency | 60Hz  |
| Rated power     | 1050w |

BILL OF MATERIAL


|   |                                                                                   |    |   |                                                                                   |    |   |                                                                                   |    |   |                                                                                   |    |
|---|-----------------------------------------------------------------------------------|----|---|-----------------------------------------------------------------------------------|----|---|-----------------------------------------------------------------------------------|----|---|-----------------------------------------------------------------------------------|----|
| 1 |  | X4 | 2 |  | X4 | 4 |  | X6 | 5 |  | X4 |
| 6 |  | X1 | 7 |  | X1 |   |                                                                                   |    |   |                                                                                   |    |

Product Parts List




### 1 Secure the decorative bracket

Secure the decorative bracket to the product with screws.



### 2 Mark the center point

Mark the drilling points on the wall according to the position of the rear fixing bracket.




#### ! NOTE

During the marking process, It is necessary to avoid areas such as the reserved wiring, water pipes, and gas pipelines within the walls.

### 3 Drill holes

Drill holes at the marked points. Use a 0.32 in/8 mm diameter drill bit.




#### ! NOTE


During the marking process, it is necessary to avoid areas such as the reserved wiring, water pipes, and gas pipelines within the walls.

### 4 Install the fixing part

Insert Expansion Sleeve into the hole.




Secure Fixing Part to the wall with Screw.



### 5 Secure the product

Install the product onto the fixing part from top to bottom.



### 6 Install the wind deflector

Install the wind deflector onto the product from bottom to top.



**7** Installation complete



For operating instructions,  
please refer to PAGE 2 -  
CONTROLLER OPERATING  
INSTRUCTIONS.



After-sales service



After-sales service

**CUSTOMER-SERVICE@PBHUSRI.COM**